

Mining Brakes and Clutches



Mining Clutches & Brakes







Mining Brakes

WPT Power's Mining Brakes and Clutches are designed specifically for heavy earthmoving equipment, such as rope shovels and draglines. These brake and clutch units are suitable for pneumatic operation, have a variety of torque capacities and pressure settings, and can dissipate large thermal loads. WPT Mining Brake and Clutch units are 100% compatible with existing installations, and multiple hub options are available.

- Interchangeable with existing installations
- Premium metallic friction linings
- Vertical & Horizontal mounting
- Available with limit switches and wear indicators



Mining Clutches

Clutches are available in 13" and 17" Options. Consult WPT Application Engineering for application assistance and applicable service factors.



Standard Mount



Paired Stud



Standard Mining Brake Dimensions

	A	В					
Model	(+0.003/ (+0.08/ -0.000) -0.00)	Hole Circle	Diameter	Quantitu	D	E	Air Inlet
	in (mm)	in (mm)	in (mm)	Quantity -	in (mm)	in (mm)	NPT
PE-113	18.872 (479.35)	17.63 (447.7)	21/32 (16.7)	8	16 5/8 (422.4)	6 9/16 (166.6)	1/2
PE-117	23.995 (609.47)	22.50 (571.5)	21/32 (16.7)	12	21 (533.4)	8 5/8 (218.4)	1/2
PE-217	23.995 (609.47)	22.50 (571.5)	21/32 (16.7)	12	21 (533.4)	11 1/16 (280.7)	1/2
PE-121	28.245 (717.42)	26.75 (679.5)	25/32 (19.8)	12	25 (635.0)	9 1/8 (231.1)	3/4
PE-221	28.245 (717.42)	26.75 (679.5)	25/32 (19.8)	12	25 (635.0)	11 1/4 (286.3)	3/4
PE-321	28.245 (717.42)	26.75 (679.5)	25/32 (19.8)	12	25 (635.0)	13 1/2 (342.1)	3/4
PE-225	32.495 (825.37)	31.00 (787.4)	25/32 (19.8)	12	29 3/4 (755.7)	14 1/8 (358.9)	3/4
PE-325	32.495 (825.37)	31.00 (787.4)	25/32 (19.8)	12	29 3/4 (755.7)	16 15/16 (430.8)	3/4
PE-130	38.995 (990.47)	37.00 (939.8)	29/32 (23.0)	12	35 1/2 (901.7)	15 1/16 (382.5)	3/4

Paired Mining Brake Dimensions

	А	В			_		J
Model	(+0.003/ (+0.08/ -0.000) -0.00)	Hole Circle	Diameter	Quantitu	D	E	Air Inlet
	in (mm)	in (mm)	in (mm)	Quantity	in (mm)	in (mm)	NPT
PE-121	28.245 (717.42)	26.75 (679.5)	25/32 (19.8)	12	25.00 (635.0)	9 3/4 (247.6)	3/4
PE-221	28.245 (717.42)	26.75 (679.5)	25/32 (19.8)	12	25.00 (635.0)	12 3/8 (314.3)	3/4
PE-225	32.495 (825.37)	21.00 (787.4)	25/32 (19.8)	12	29 3/4 (755.7)	13 7/8 (352.4)	3/4
PE-325	32.495 (825.37)	21.00 (787.4)	25/32 (19.8)	12	29 3/4 (755.7)	17 7/8 (454.0)	3/4

Mining Brake Specifications

	Torque Rating @ 60 psi (4.1 Bar)*					
Model	Static Torque	Total Weight Less Hub Drive Plate Weight		Drive Plate Inertia	Lining Area	
	lbf-in (N-m)	lb (kg)	lb (kg)	lbf•ft² (kg•m²)	in² (cm²)	
PE-113	21,700 (2450)	180 (82)	16 (7)	2.6 (0.11)	90 (580)	
PE-117	44,500 (5030)	350 (160)	34 (16)	8.5 (0.36)	134 (870)	
PE-217	82,200 (9290)	470 (210)	60 (27)	16 (0.66)	270 (1700)	
PE-121	86,700 (9800)	520 (240)	43 (20)	17 (0.73)	200 (1300)	
PE-221	158,000 (17900)	660 (300)	96 (44)	35 (1.5)	400 (2600)	
PE-321	212,000 (24000)	880 (400)	150 (69)	55 (2.3)	600 (3900)	
PE-225	278,000 (31400)	1,200 (530)	150 (69)	89 (3.8)	540 (3500)	
PE-325	386,000 (43600)	1,500 (680)	230 (110)	130 (5.4)	810 (5200)	
PE-130	272,000 (30700)	1,600 (700)	100 (46)	84 (3.5)	340 (2200)	

Consult WPT Application Engineering for application assistance, service factors, specifications, and detailed drawings/3D models. *Dynamic (slipping) Torque is 75% of the Static Torque.

NOTE: Contact WPT for other available torques and release pressures.

Limit & Temperature Switches





Types of Sensors

Most brakes are equipped with limit switches and temperature switches for onboard diagnostics. These sensors alert the operator if the brake's operation is in a condition requiring maintenance.

They can include:

- Thermal Sensor Indicates when the brake is working at a non-recommended temperatures.
- Release Switch Indicates to the operator and the control system that the brake is released.
- Wear Switch Indicates that brake lining and the discs are worn, and the brake needs an adjustment.



Why WPT's Kits?

Our Actuator Switch Kit for rope shovels and draglines has an improved design over previous generations, allowing for easier adjustment and appreciable serviceability. WPT Power's kits include shims that allow for greater adjustment during switch installation. Shims can be added on top of the cylindrical standoffs to adjust the wear switch's trigger point or beneath the aluminum target block to adjust the release switch's trigger point.

The real-time monitoring of the brake's temperature, wear, and operation will provide optimized performance and safety over the brake's lifespan.

Sensor Kits Available For:				
Wire Rope Shovels	Brakes			
	Hoist			
Bucyrus 459HR / CAT [®] 7495 HR	Crowd Y Swing			
	Temperature			
Komatsu [®] (P&H) 4100 XPB	Hoist			
Komatsu [®] (P&H) 4100 XPC	Crowd Y Swing			

For application assistance, service factors, and specifications in recommending sensor kit(s), consult WPT Application Engineering.





Global resource network

Our qualified distributor network provides responsive and knowledgeable sales and technical support worldwide. WPT's customer care approach ensures your product needs will be met quickly and with minimum downtime – when and wherever you are.

Regional Offices

Canada & USA info@wptpower.com

Australia, Africa & Asia asiapacific@wptpower.com

South America & Mexico southamerica@wptpower.com

United Kingdom & Europe europe@wptpower.com

Distributed by:

WPT Power Corporation

1600 Fisher Road Wichita Falls, Texas 76305 U.S.A.

P.O. Box 8148 Wichita Falls, Texas 76307

+1 940-761-1971 Phone WPTpower.com

WPT Power (Shanghai) Ltd.

No. 3-4 Building 669 MinTa Road Songjiang, Shanghai, PRC 201617

+86-21-57847560 Phone WPTpower.cn

WLB-PE-000 B